

PRO SERIES

LEMON CHARGE

DISH WASHING DETERGENT

LIMPIADOR/SOSTÉN

Technical Data

Areas of Use

- Dishes
- Glassware
- Utensils
- Pots and Pans

Specifications

SSS Item Numbers48120Ž(, %&)
 Available Sizes1GŽ));
 Active Ingredients18.0 ± 0.5%
 ColorYellow
 FragranceLemon
 pH7.5 - 8.0
 ViscosityHigh
 FoamHigh and stable
 AbrasivesNone
 SolubilityComplete with water
 EmulsificationExcellent
 DetergencyExcellent
 RinsabilityExcellent
 Physical StateLiquid
 Flash PointNone (waterbased)
 BiodegradabilityComplete
 Storage/Stability2 years
 Weight Per Gallon8.50 lbs./gal.
 Freeze/Thaw StabilityKeep from freezing

HMIS Hazardous Materials I.D. System

Health1
 Flammability0
 Reactivity0
 Personal ProtectionA

What the Pros Know

Permit spigot to run with force to increase foaming action of dish detergent. It will not be necessary to scrub pots, pans and dishes.

Description

A liquid detergent that leaves skin smooth and soft, yet produces oceans of suds instantly that will cut through food and grease deposits faster than any other dish washing detergent available. Makes dishes, glassware, and utensils sparkle without scratch, acid or alkali action.

Directions

Wear safety equipment recommended on MSDS, place Wet Floor Signs and read all directions and cautions prior to beginning your work.



FOR DISHES, GLASSWARE AND UTENSILS: Use 2 ounces per sink full of water and permit water to run with force until sink is filled to usual level. Wash dishes, rinse and permit to air dry. It is not necessary to wipe as both dishes and glasses will dry to a spot free sparkle. Removes lipstick from glasses without effort. Will not affect head on beer.

FOR GREASY POTS AND PANS: Cleans greasy pots and pans without effort. Merely use a tablespoon to each pan, fill with hot water, and let stand while other dishes are being washed. Then wash in the usual manner.



Suds Instantly

Easily Cuts Grease and Food Soil

Leaves Skin Smooth and Soft

