



BRIGHT FORCE

OVEN & GRILL Cleaner

High foaming cleaner quickly penetrates and liquefies baked on food, grease, and carbon deposits from commercial ovens, grills, fryer baskets and other kitchen equipment. Provides the kitchen with a cleaner look and improves performance of cooking appliances.

Directions

Oven

- Spray product to bottom, top and sides evenly.
- Let it set for 10 minutes in a warm oven, 25 minutes if in a cold oven.
- Gently agitate soil with synthetic pad or brush.
- Rinse thoroughly with a damp cloth or sponge.
- Heat oven to 220°F before cooking additional foods.

Grill Top

- Scrape warm surface with wire brush or grill block to remove excess soil.
- Spray product to grill and let it set for 3 minutes.
- Gently agitate and remove soil.
- Rinse thoroughly.

Features

- Quickly Cuts Baked on Food, Grease & Carbon Deposits
- High-Foaming
- Phosphate Free
- Deep Cleaning
- Biodegradable
- Non-Flammable

Recommended For

- Ovens
- Steamers
- Grills
- Cook & Hold Ovens
- Broilers
- Rotisserie Ovens
- Fryers
- Drip Pans



Specs

- Dilution:** RTU
- pH Level:** 13.0-14.0
- Color:** Colorless
- Fragrance:** Mild
- Pack:** 12/32 oz. (#25107)

Fast acting on hot or cold surfaces.