



# NAVIGATOR

## Dilution Control System

### Why It's A Better System

- Concentrate and RTU labels are numbered and color coded for safety and to facilitate training
- Closed system - Spill proof container
- New Metered Tip with each concentrate provides proper dilution each time
- English/Spanish label copy
- Each concentrate has an easy carry handle
- Recyclable container

### Why It's A Better Cleaner

- For use against Novel Coronavirus SARS-CoV-2, the Cause of COVID-19 (EPA List N).
- Kills *Clostridium difficile* spores in 2 minutes.
- Effective against Multidrug Resistant Organisms (MDROs) (*Staphylococcus aureus*, (Resistant to Methicillin (MRSA), *Staphylococcus aureus*, (Genotype USA300) (Community Associated Methicillin Resistant) (CA-MRSA), *Staphylococcus aureus*, (Genotype USA400) (Community Associated Methicillin Resistant) (CA-MRSA), *Staphylococcus aureus*, (Intermediate Vancomycin Resistance) (VISA), *Enterococcus faecalis* (Resistant to Vancomycin) (VRE), *Escherichia coli* (Extended-Spectrum Beta Lactamase producing) (ESBL), *Klebsiella pneumoniae* (Carbapenemase producer) (KPC).
- Leaves no visible residue.
- Designed for daily use on common materials found in hospitals.
- May be used to clean and disinfect finished floors. Cleans and disinfects without dulling gloss.
- No harsh bleach smell.
- Is an economical concentrate (that can be diluted for use) (with a mop and bucket, cloth, microfiber cloth, sponge, coarse spray device or by soaking).

### How It Cleans

FOR USE WITH MICROFIBER CHARGING SYSTEM: Put on gloves/eyewear. Dispense diluted solution per the chart below into a secondary bottle or bucket. Pour contents into a microfiber charging bucket containing microfiber cleaning cloths. Allow 15 minutes for solution to saturate microfiber. Fold cloth into quarters and apply product by wiping the surface.

FOR USE IN MICROFIBER CHARGING:  
Fill microfiber charging bucket according to chart below

Type	Qty	Diluted Solution
16"x16" microfiber cloths	15	32 oz
	24	64 oz
	40	96 oz
	50	1 gal

### Navigator Dispensers

- #23200 Navigator DCS 4-Button Dispenser
- #23201 Navigator DCS 1 Button Dispenser, bottle-fill
- #23202 Navigator DCS 1 Button Dispenser, bucket-fill
- #23203 Navigator DCS Portable Dispenser
- #23209 6 ft. Water Supply Hose, Black

NAVIGATOR 2-Liter bottles are designed to be used in the NAVIGATOR Dilution Control System.

# 62 PERISEPT

## SPORICIDAL DISINFECTANT CLEANER

### DISINFECTANT

### Where It Cleans

- Hospitals
- Nursing Homes
- Critical Care Units (CCU)
- Doctor Offices
- Operating Rooms
- Veterinary Clinics
- Schools
- Finished Floors
- Aluminum
- Baked Enamel Surfaces
- Brass
- Chrome
- Glass
- Glazed Ceramic Tile
- Glazed Porcelain
- Laminated Surfaces
- Plastic and Painted Surfaces
- Plastic Surfaces
- Polished Nickel Finish
- Shower stall
- Stainless steel
- Vinyl

### Technical Data

Packaging (concentrate):.....2/2 Liters per case  
 Product Number: .....48027  
 Dilution: ..... 1:32  
 Color:.....Clear  
 Odor:.....Mild vinegar-like  
 pH: ..... < 1.0  
 RTU pH:..... < 2.0  
 Viscosity:..... Water thin  
 Flash Point:..... 83°C (PMCC)  
 Storage/Stability:..... 1 year  
 Rinsability:..... Excellent  
 Weight Per Gallon: ..... 9.40 lbs. per gallon  
 Freeze/Thaw Stability: ..... Keep from freezing  
 RTU Quart Yield: ..... 68 Quarts per bottle  
 Gallon Yield: ..... 17 Gallons per bottle  
 EPA#:..... 10324-214-12120

